



Installation Instructions Frameless Glass Balustrade

Tools and accessories required to carry out the installation:

- Full Vertical upright – U channel
 - 2 x Nylon seating blocks
 - 12 screws (delta concrete frame anchor 100mm x 6.5mm)
 - E gasket
 - 4mm Wedge gasket
 - 4 x 28mm Plastic trims
 - 2 x Top caps
1. Screw the vertical rails to the sides of the door/tilt & turn, with 2 screws top and bottom of each rail. Install the door making sure it is square and plum within the tolerance of 2mm max.
 2. Fix the door in 3 places, 150mm from bottom/ 150mm from top and centre, fixing through the door and rail into the structure of the building. Making sure it is packed correctly and firmly fixed.
 3. Shuffle glaze the glass into position ensuring that the glass is 100mm higher than the frame when shuffle glazing and lower onto nylon blocks and even the glass in its frame. This should be 15mm either side into the frame.
 4. Use wedge gasket provided to back wedge the glass so its fixed into position.

PLEASE NOTE if the product is not installed to these instructions correctly it can pose a serious risk and cause harm or even death.

If you have any problems with the installation of this product, please do not hesitate to contact us and we will help guide you through it.

Glass Roofs UK

trading as Total Installations Limited
102-120 North Lane – Aldershot – Hampshire – GU12 4QN
Tel: 01252 336614 – Fax: 01252 341035
Email: sales@totalinstallations.com
Website: www.glassroofsuk.com